

## FLAT SCREEN KEYBOARD TRAY

**Notes:** There are four (4) flathead screws that go through the keyboard platform into the bottom of the L-shaped support and are fastened with washers and acorn nuts. The mouse platform comes attached to the platform. The U bracket that is part of the flat screen arm is used to support the keyboard tray. The flat screen arm does not need to be disassembled to attach the tray.

1. Insert two 1/4-20 screws through the clearance holes in the clamping strap.
2. Place three washers on each of the screws. The washers act as spacers to account for the material

thickness of the U bracket in this "sandwiched" assembly.

3. Align a set of tapped holes in the L support with the screws and tighten the screws.
4. Insert the set screw into the tapped hole in the bent flange on the clamping strap. Adjust set screw to square up the assembly.
5. Attach Keyboard Platform to L-Support with 4 - #8-32 screws, washers and acorn nuts.

