

## Floor Case

### Product Numbers

- LUCFxyy

To prevent tipping, floor case units (Illustration 1) must be secured to a wall or otherwise supported vertically.

After leveling the units, install fasteners through the holes in the back of the cabinet, near the corners if possible, into the wall. At least three fasteners are recommended per left and right side of the cabinets (see Illustration 2).

The floor case must be securely fastened to the wall system before use.

Illustration 1



Illustration 2

