

WRIST STRAP GROUNDING KIT

The surface is not pre-drilled for the Wrist Strap Grounding Block. Fasten ground block to surface before installing the surface on the frame.

1. Using the block as a template mark the mounting hole location on the underside of the surface. Drill two (2) 1/8" diameter x 1/2" deep holes.
2. Attach one end of coiled ground cord to threaded hole in the grounding block using the 1/4-20 x 3/8" sems phillip screw provided.
3. With flat side down and coiled cord facing to rear of surface, fasten block to surface with two (2) 10-12 x 1" phillips screws provided.
4. Attach free end of coiled cord to installed ESD Laminate Grounding Terminal, ground attachment point to an appropriate path-to-ground.

