

## POWERTOP®

**Note:** The PowerTop comes factory assembled. It requires two people to install the unit in a workstation. The instructions illustrate a Profile C PowerTop.

1. Engage right-hand bracket support in right corner frame at designated height. Push support down to securely seat in hanger frame. Repeat procedure with left-hand support in left frame.

### For PowerTop Profile A & B

2. Engage additional right-hand bracket support in corner. Place A or B reference level surface over brackets, aligning all holes. Fasten each bracket to top with two (2) #10-12 x 3/4" pan head phillips screws provided.

### For PowerTop Profile C (illustrated)

3. Engage pan support bracket 9" lower than the cantilevers. Place C reference level surface over brackets, aligning all holes. Fasten each bracket to top with two (2) #10-12 x 3/4" pan head phillips screws provided. Install a #10-24 x 3/8" thread cutting screw through the bottom of the pan support bracket into pan assembly.

**PowerTop A & B Hardware Pack - PTAHP (#97010904)**

**PowerTop C Hardware Pack - PTCHP (#97010905)**

