

## DISSIPATIVE MATS

Mats include a 10' grounding cord with resistor, 10mm socket and ring terminal. Wrist straps are not provided by Symbiote.

1. Place mat on surface. Attach grounding cord to appropriate snap in mat.

### Grounding to a Dissipative Surface

2. Attach grounding cord's ring terminal to the installed ESD Lamine Grounding Terminal on the dissipative surface.

### Grounding to a Frame

3. Attach grounding cord's ring terminal to one of the frame's two (2) threaded grounding locations with the 1/4-20 sems screw provided or to other appropriate path-to-ground.

### Cleaning

4. Use Antistatic cleaners only. DO NOT use cleaners with silicone, it will interfere with the mat's dissipative properties.

