

MODESTY PANEL

The MP18XX are designed for Open Frames and the MPU18XX are designed for Ultra Frames.

1. Install #10 x 3/8" phillips screws into each hanger clip at opposite ends, leaving a 3/16" gap between screw and clip.
2. At desired mounting height, attach hanger clips on the left and right-hand side of frame with the screws at the top.

3. Measure down 17" from top of hanger clip and install second pair of clips without screws.

4. Align large end of keyhole slots on Modesty Panel with screws. Slide panel down over screws to engage. Secure bottom of modesty panel with two (2) additional screws. Securely tighten all screws.

Modesty Panel Hardware Pack - MPHP (#96022601)

