Floor Case

Product Numbers

- LUCFxxyy

Hardware Pack: none

To prevent tipping, floor case units (see Illustration 1) must be secured to a wall or otherwise supported vertically.

After leveling the units, install fasteners through the holes in the back of the cabinet, near the corners if possible, into the wall. At least three fasteners are recommended per left and right side of the cabinets (see Illustration 2). The floor case must be securely fastened to the wall system before use.

CAUTION: Install a filler block of wood in the cavity behind the floor case, where the fasteners will go into the wall, to keep the cabinets's back flat and free of dimples.

Illustration 1

Illustration 2