


ErgoStat® Pro

SHELVING Display Shelf


PRODUCT NUMBERS
PDS24, PDS30, PDS36

HARDWARE PACK
PADHP (p/n 16091401-01)


REQUIRED TOOLS
None



1. Shelf can be oriented with lip up or down. Insert hooks in the shelf sides into slots in ErgoStat Pro Riser Frame. Push shelf down to ensure it is firmly seated.



2. Insert tip of anti-dislodgement clip into slot above top hook of shelf as shown.



3. Rotate anti-dislodgement clip down until bottom of the clip snaps into the hole near the top hook of the shelf. Repeat on opposite side.