

## CORNER LAMINATE SHELF

The Corner Laminate Shelf requires three supports which are included with the shelf.

1. Engage right-hand cantilever support in right corner frame at designated height. Push support down to securely seat in frame. Repeat procedure with left-hand support in left frame and a corner support in corner.

2. Place shelf over supports aligning front set of holes in handed brackets and the two holes in the corner support with predrilled holes in surface bottom. Fasten with two #10-12 x 3/4" Phillips screws provided per support.

### Dissipative Laminate Shelf

A dissipative shelf comes with a Laminate Grounding Terminal (LGT3). The terminal is used to ground the shelf to the frame. Install the LGT per attached instructions.

Surface Accessories Hardware Pack - SFAHP (#96011201)  
Corner Shelf Brackets Hardware Pack - SPTB12.3-finish (#99010502 -finish)

