

## TOOL HOLSTER & SURFACE AIR BRACKETS

*Quick Disconnect fittings come pre-installed on the Tool Holster and Surface Bracket with air.*

1. Determine desired location of bracket on underside of surface. Using bracket as a template, mark two (2) location holes for mounting.
2. Pre-drill two (2) holes 1/8" dia x 1/2" deep. Align bracket with holes and fasten beneath surface using two (2) #10-12 x 1" phillips screws provided.

### Brackets with compressed air

3. Push tube provided into adapter on back side of bracket. Using the tube clip, manage tube on underside of surface, connecting tube to building source or to another QD fitting on Air Strip or Utility Distributor.

4. A coiled air hose (CAC1/2) may be required to connect air to the tools, this is a separately ordered item.

*Tool Holster requires a Surface Accessory Hd Pk - SFAHP (#96011201)*

*Tool Holster & Surface Bracket w/Air Hd Pk - THAHP (#97031402)*

