

SURFACE LEVELING PLATE

Provides additional outboard support on surfaces. Fastens to underside of adjacent surfaces. Sized to fit in front of Surface B Support Brackets and Cantilever Supports. **Note:** Not to be used to attach peninsula surfaces to adjacent surfaces.

Mounting Location

1. Hold surface leveling plate to bottom of adjoining work surface 1/4" from work surfaces' front edges and 1-1/2" from joint between surfaces.

Attachment

2. Mark hole locations. Drill two 1/8" x 1" deep pilot holes. **Note:** Do not drill holes deeper than 1". Fasten with two #10-12 x 1" phillips screws provided.

