

# ErgoStat® Pro

## STORAGE / ACCESSORIES

### Riser Panel Tackable Insert

## PRODUCT NUMBERS


PPT29xx

## HARDWARE PACK


none

## REQUIRED TOOLS

none



1. Center the width of the Tackable Insert between the flanges of the Riser Panel near the top.



2. Slide insert up to the top flange of the Riser Panel and then press bottom of insert into the bottom of the panel. Ensure all magnets on the back of the insert are contacting the Riser Panel.