Task Light Lens, Batwing

Product Numbers
- L2xxSE

Required Tools
- none

Hardware Pack: TLBHP (p/n 88081606)

1



Lay the Task Light upside down on a clean, smooth surface.

2



With the rough side of the lens facing the lamps, insert the rear lens flange under the back lip of the Task Light.

3



Gently insert the front flange of the lens under the front lip of the light. Install Task Light as required with brackets, ordered separately.