TASK DRAWER MASTER KEY AND CONTROL KEY

The Task Drawer has a removable and installable lock core system for your convenience.

1. To remove cylinder core/plug, insert **master key** and turn to unlocked position. Then using the **control key**, remove the core.

2. Master key will unlock any plug beginning with the prefix ELS.

3. Install new core by following the above steps in reverse order.

Task Drawer Lock Set with Keys - ELS*

Key numbers available (226-325)

Task Drawer Key Set; control and master - MCK



©Symbiote®, Inc. • 300 North Centennial Street • Zeeland, MI 49464 • Phone 616.772.1790