Positionable Adjustable Bases, Work Surfaces

Product Numbers
- ESPLC... ESPLG...
- TBPLC... TBPLG...
- WTPLC... WTPLG...

Hardware Pack: ETWPHP (p/n 93082504)

Required Tools
- 3/16" Allen Wrench
- #2 Phillips Bit
- Cordless Drill/Driver

Notes:
- For commercial use only.
- This product is shipped fully assembled and has no user serviceable parts. Servicing is to be performed by an authorized service representative only.
- Worksurfaces are composed of a particleboard core when used with stainless steel or laminate. Surfaces may also be composed of phenolic or epoxy resin. Minimum thickness is one inch.
- Maximum surface width: 24" greater than width of base.
- Maximum surface depth: 48" for 36" deep base; 36" for 30" deep base; 30" for 24" deep base.
- Maximum load is 100 lbs.

WARNING: Do not tighten the #10-12 surface screws more than 25 in-lbs. in laminated surfaces or 40 in-lbs. in phenolic surfaces.

Figure 1a: Glide Base



Figure 1b: Caster Base

Figure 2



1. Place base in desired location. For glide bases, level the base by adjusting the four glides on the bottom of the feet (Figure 1a). For caster bases, apply the caster locks (Figure 1b) when base is in use.
2. To adjust height, remove the 5/16"-18x3/4" socket flathead screw using a **3/16" Allen wrench** (Figure 2).
3. While supporting the weight of the top of the base, pull out ring of pull pin and adjust leg up or down in one inch increments to desired position. Let go of pull ring so pull pin re-engages in inner leg and align countersunk hole in outer leg with a tapped hole in inner leg. Reinsert socket flathead screw and tighten to 110 in-lbs. with a **3/16" Allen wrench** (Figure 2).

Positionable Adjustable Bases, Work Surfaces

WARNING: Do not tighten the #10-12 surface screws more than 25 in-lbs. in laminated surfaces or 40 in-lbs. in phenolic surfaces.



Figure 3: **ErgoStat**, 30-42" D Work Surface



Figure 4: **WorkTable**, 30-42" D Work Surface



Figure 5: **Table Base**, 24-26" D Work Surface



Figure 6: **Table Base**, 27-42" D Work Surface

4a. The back edge of the ErgoStat base (Figure 3) should be 1¼" from the back edge of the work surface. Properly align the ErgoStat base support brackets, left and right, over the predrilled holes of the work surface.

4b. Center the WorkTable base (Figure 4) front and back, left and right, over the predrilled holes of the work surface.

4c. The back edge of the Table Base should be 1¾" (Figure 5) or 4½" (Figure 6) from the back edge of the work surface. Properly align the Table Base support brackets, left and right, over the predilled holes of the work surface.

5. Once properly aligned, insert the #10-24x¾" pan head screws into the bracket holes and tighten with a **#2 Phillips Bit** or **screwdriver**.