

DISSIPATIVE MATS

Mats include a 10' grounding cord with resistor, 10mm socket and ring terminal. Wrist straps are not provided by Symbiote.

1. Place mat on surface. Attach grounding cord to appropriate snap in mat.

Grounding to a Dissipative Surface

2. Attach grounding cord's ring terminal to the installed ESD Laminated Grounding Terminal on the dissipative surface.

Grounding to a Frame

3. Attach grounding cord's ring terminal to one of the frame's two (2) threaded grounding locations with the 1/4-20 sems screw provided or to other appropriate path-to-ground.

Cleaning

4. Use Antistatic cleaners only. DO NOT use cleaners with silicone, it will interfere with the mat's dissipative properties.

