

## **Epoxy Resin Surface**

Mechanical fasteners are not a recommended means of attachment. The use of these types of fasteners can cause fastener shearing and/or surface fracturing.

It is recommended that epoxy surfaces be attached using a 100% silicone adhesive. Areas that adhesive will contact need to be clean and free of contaminants. Apply a liberal bead of 100% silicone adhesive to mounting face of supports the surface will mount to. Place surface in desired location. The adhesive will set firmly, and breaking this bond is extremely difficult. Ensure the room temperature is 60° or warmer for better results. Clamp in place and wipe away excess adhesive. Remove clamps once adhesive has cured.

## **Epoxy Resin Backsplash**

Mechanical fasteners are not a recommended means of attachment. The use of these types of fasteners can cause fastener shearing and/or backsplash fracturing.

It is recommended that backsplashes be attached using a 100% silicone adhesive. Areas that adhesive will contact need to be clean and free of contaminants. Apply a liberal bead of 100% silicone adhesive to mounting face of backsplash. Place backsplash in desired location. The adhesive will set firmly, and breaking this bond is extremely difficult. Ensure the room temperature is 60° or warmer for better results. Clamp in place and wipe away excess adhesive. Remove clamps once adhesive has cured.